

Order parts online
www.follettice.com

Installation Instructions

Tools required

- #2 Phillips screwdriver
- 1/2" Wrench and 1/2" socket

Materials supplied

- (4) Wall brackets
- (4) Wall anchor brackets
- (4) 5/16" bolts
- (4) 5/16" nuts
- (4) 5/16" lock washers
- (8) 5/16" flat washers
- (12) #10-32 screws

Installation

Note: If you are using this in a food service application and installing in accordance with NSF, you must seal the unit to the floor once it is set in place. Place a 1/8" bead of NSF-approved silicone sealant (not provided) around the base of the unit.

1. Attach wall anchor brackets (4) into wall stud using hardware and installation method suitable to application and local codes (**Fig. 7.1**).
2. Attach wall bracket to unit with two #10-32 screws (**Fig. 7.2**).
3. Repeat steps 1-2 to install additional wall brackets in other positions.
4. Move unit into place, align wall bracket with wall anchor bracket and secure each with bolt, two flat washers, lock washer, and nut (**Fig. 7.3**).

Note: CA installations require two wall anchor brackets installed at top AND bottom of units. Go to Follett website <http://www.follettice.com/misc/oshpd.asp> for CA seismic anchorage information for "Stacking refrigerators and freezers." The wall brackets on the bottom unit should be mounted near the floor level.

Fig. 1 Wall brackets



